


Features:

1. Oil less, no air polluted.
2. Smart and convenient to take.
3. Low noise, around 50db. (Different model have different noise level)


Application field:

1. Vacuum for the package of elastomeric goods, clothes and so on.
2. Vacuum package for food.
3. Producing craft, toys and vacuuming on air condition.


4. AS20W can be used for inflating on different balls and cars, also can be used for airbrushing purpose.
5. For medicament, environment protection, laboratory and other industrial equipment.



AS20




AS20-1




AS20W



AS30W



AS26



AS29

Mini Vacuum Pump

Model	Power	Speed/mim		Vacuum Degree	Air flow	Max pressure		N.W.	Single Dimension	Carton Dimension	PCS/CTN	Weight
	HP	220-240V 50HZ	110-120V 60HZ	Vacuum Degree	L/min	BAR	PSI	KG	L*W*H	L*W*H	PCS/CTN	N.W./G.W.
AS20	1/5	1450	1700	600mmHG	20-23	—	—	3.4	25.5*13.5*17	44.5*27.5*39.5	6	20.4/22.4
AS20-1	1/5	2900	3400	650mmHG	35-40	—	—	3.6	25.5*13.5*17	44.5*27.5*39.5	6	21.6/23.6
AS26	1/4	1450	1700	600mmHG	65-68	—	—	4.6	30.5*12.5*17	44.3*28.6*40.5	6	27.6/29.6
AS29	1/3	1450	1700	600mmHG	128-135	—	—	9.1	43*16.5*23	38*38*25.5	2	18.2/20.2
AS20W	1/5	1450	1700	650mmHG	20-23	—	—	3.4	21.5*13.5*17	44.5*27.5*39.5	6	21.6/23.6
AS30W	1/4	1450	1700	650mmHG	35-40	7	100	5.5	33*13.5*20.5	67*39*26	4	22/24

Note: AS20W can be used as vacuum pump or air compressor, please use it as vacuum or air compressor according your requirement by exchange the muffle.

Notice:

1. Before connecting the compressor, check that the mains voltage complies with the electrical characteristics of the Motor.
2. Please follow local electrical rules, and safety rules. And the use the socket which must be earthing.
3. Please choose the right model of vacuum pumps according to the real purpose, especially pay attention to the max vacuum degree and the air flow.
4. The outlet of vacuum pump is 1/8" or 1/4", please choose the right outlet or adapter to suitable for your requirement.
5. Make sure all the connection is airtight. Any leakage will affect the performance of the machine.
6. The vacuum pump must be used in suitable environments (well - ventilated , with an

ambient temperature between +5°C and +40°C)

7. Never leave the appliance exposed to dust, acids, vapors, explosive or flammable gasses or atmospheric agents (rain, sun, fog, snow).
8. Never use the appliance in your bare feet or with wet hands or feet.
9. Do not allow inexperienced persons to use the vacuum pump without suitable surveillance. Keep children and animals at a distance from the work area.
10. Never allow the children to touch the working machine or insert the stick into the machine. It will cause the danger of scald or get an electric shock.
11. Do not open or tamper with any part of the compressor. Contact an authorized Service Center.

Instruction Manual

Thanks for purchasing our mini vacuum pump, please read this Instruction Manual carefully and thoroughly before operating the tool to get best performance.

Model: AS20 AS20-1 AS20W
AS30W AS26 AS29

